



A MITEL
PRODUCT
GUIDE

OpenScape Business V3

SIP Trunk configuration

Mobile Extension (MEX) Connectivity

Release Number 09/2024

Contents

History of Changes	3
1 Introduction	4
2 Preconditions	4
3 Configuration example	5
3.1 MEX originated call.....	6
3.2 MEX terminated call (to fixed network number)	7
3.3 MEX terminated call (to mobile number)	7
4 How to Configure SIP MEX	8

History of Changes

Date	Issue	Summary
28.02.2018	1.0	Create new document (taken from ITSP configuration guide)
26.09.2024	1.1	editorial changes

Note: The basis for this document is the current OpenScape Business at the time of certification. Since OpenScape Business is constantly developed, input masks and interfaces as well as requirements may change in the future. The settings and entries described here then apply accordingly.

Comments and corrections are welcome, please contact: osbiz-certification@mitel.com

1 Introduction

The main concept of the feature is that the MEX device can be used as an internal station over the GSM network. MEX device can make calls to other internal OpenScape Business stations and dial out via the ITSP trunk. MEX terminated calls will be handled as standard mobility calls.

OpenScape Business supports this feature for ITSP trunks only. SIP MEX implementation is based on the existing Mobility feature. Therefore, the conditions and relations to other features are identical to mobility, if not otherwise mentioned.


2 Preconditions

- SIP MEX feature must be supported by the relevant ITSP/GSM Carrier.
- ITSP must be configured in public number / DID mode
- LCR must be activated
- ITSP must use dialable number format. In other words, including international/national prefixes (e.g. 0049xxx / 089xxx). E.164, implicit international/national formats are not supported (e.g. +49xxx, 49xxx, 89xxx are not supported).
- Since the feature is based on Mobility, a mobility license is required for every SIP MEX user.
- A DISA number must be configured
- ITSP access and configured mobility extension must be located at the same node.

In the following pages a detailed configuration example is available.

3 Configuration example

Scenario Example:



OpenScape Business Configuration

Based on above example image:

- ITSP is using national dialable format
- 0 is the national prefix
- 857 is the ITSP LCR prefix (by default)
- 35800 is the MEX prefix

3.1 MEX originated call

a) MEX user (mobile phone) calls internal station 102 by dialling 102. ITSP will route the call to OpenScape Business with the following info:

```
Incoming INVITE
FROM: 06972801200
TO: 35800102
```

OpenScape Business will recognize that this is a MEX call from the number that is configured as mobility user. The destination number 102 will be extracted from TO and then handling will be mapped to feature 'Call Through' so that a call to the internal station 102 is initiated.

b) MEX user (mobile phone) calls external phone by dialling 8570898075412. ITSP will route the call to OpenScape Business with the following info:

```
Incoming INVITE
FROM: 06972801200
TO: 358008570898075412
```

OpenScape Business will recognize that this is a MEX call from the number that is configured as mobility user. The destination number 8570898075412 will be extracted from the TO and then handling will be mapped to feature 'Call Through' so that a call to 0898075412 is initiated over the ITSP trunk. In the outgoing INVITE the originator will be the public number of the MULAP (or the virtual station's that is binded with Mobility-if no MULAP is set).

This example described operating mode "Dialling external numbers with seizure code". In other words, the mobile user will dial also the ITSP seizure code 857 (or the ITSP will send it in TO field). Therefore, the system flag "Add Seizure code for MEX" must be deactivated. If the incoming INVITE will not include 857 in the TO header (user will not dial 857 or the ITSP will not send it) then OpenScape Business can add it automatically. In that case system flag "Add Seizure code for MEX" must be activated.

The algorithm to differentiate between internal and external destinations when flag 'Add seizure code for MEX' is activated is the number of digits. If destination is >7 digits then number is assumed as external, thus seizure code is added. If destination is <=7 digits, then it is considered as internal destination.

As the only indication for the algorithm to differentiate between internal and external destinations in the operating mode 'add seizure code for MEX' (= dialing external numbers without seizure code) is the number of digits, the functionality depends on the numbering scheme of the node /network and this mechanism can be activated / deactivated by WBM configuration. It is only suitable in networks with internal numbers with a maximum length of 7 digits and must be deactivated, when this condition is not met.

3.2 MEX terminated call (to fixed network number)

External phone calls MEX user by dialling the public number of the virtual user of the OpenScape Business.

The incoming INVITE from ITSP will contain:

```
FROM: 0892108075412
TO: 02108196100
```

The further handling is the processing of a call to a mobility user as it is already implemented so that a call to mobile 06972801200 is initiated (via ITSP trunk). In the outgoing INVITE the originator will be the public number of the virtual station (02108196100). * Please note that if the ITSP is configured to display the original caller in transit scenarios, then the FROM field will have 0892108075412

3.3 MEX terminated call (to mobile number)

This is not a typical scenario. Some ITSP's require that the MEX mobile number is accessible with second MEX prefix. This second MEX prefix can be configured only in Expert Mode and is not available in wizards.

External phone 0892108075412 calls MEX mobile phone 06972801200. ITSP will route the call to OpenScape Business. The TO field will/may be equipped with an additional prefix2 (e.g. 35801).

The incoming INVITE will contain:

```
FROM: 0892108075412
TO: 3580106972801200
```

The destination will be mapped to the MEX mobile number using the resp. ITSP tables (see Voice Gateway configuration). In other words, even if the ITSP is set to operate in public number / DID mode, only for this case a manual MSN entry must be created in ITSP profile in Voice Gateway with following info: MSN: 3580106972801200 mapped to internal virtual station 103. The further handling is the processing of a call to a mobility user as it is already implemented; a call to MEX mobile 06972801200 is initiated.

Remark: Some providers may use a leading prefix 3. This is not supported in OpenScape Business.

Additional info:

- In OpenScape Business Embedded features in call state (e.g. consultation) can be activated with DTMF dialling (standard use of feature 'Mobility'). Here '*' and '#' can be used or the substitution codes for '*' and '#'. The configuration as for standard use of feature 'Mobility' is necessary i.e. station orientated bit 'DTMF based feature activation' must be set in WBM.
- For the virtual user a MULAP or a single configuration can be used (as standard use of feature 'Mobility')
- For emergency numbers (e.g. 110 and 112) respective LCR rules must be defined (e.g. '11' -> ...). Here collisions with the call numbers of the systems must be avoided (no call numbers should begin with 11).

4 How to Configure SIP MEX

Since MEX feature is based on Mobility feature, then a Mobility user must be configured over the ITSP trunk. The same applies also for DISA number (please refer to official documentation for Mobility for further information and configuration hints).

MEX prefix is configured in ITSP wizards in Internet Telephony Station (see image below). As already mentioned, ITSP must be configured in “Public Number (DID)” mode.

Please note that the ITSP must be activated to add the MEX prefix or activate the enable ITSP checkbox when creating the profile for the first time.

MEX supported: ▾

If the ITSP is not activated, then the MEX number field will not be editable. MEX prefix can be up to 8 digits.

Setup - Wizards - Central Telephony - Internet Telephony

Internet Telephony Station for myITSP MEX

Internet telephony station:

Authorization name:

Password:

Confirm Password:

Call number assignment

▾

ITSP-multiple route:

Default Number:

MEX Number:

Default Number
ITSP as primary CO access
Enter one of the call numbers supplied by your network provider here. This will be used in outgoing calls as the calling party number in case no other number is available for the respective call.
All call numbers supplied by your network provider are to be entered within the trunk and telephones configuration (DID field) primary CO access.

MEX Number
To use the feature Mobile Extension (MEX) you have to enter a MEX number here. An entered MEX number will only be stored if the ITSP is marked as 'active'.

Help Abort Back OK & Next Delete Data

Please keep in mind that the ITSP must be configured to use dialable international/national format. Therefore flag “Call No. with international / national prefix“ must be activated in ITSP Route > Routing Parameters (for more info please refer to the “use Public Number DID” Mode chapter).

Route

Change Route Change Routing Parameters Special Parameter change

Routing flags

Digit repetition on:

Analysis of second dial tone / Trunk monitoring:

Intercept per direction:

Over. service 3.1 kHz audio:

Add direction prefix incoming:

Add direction prefix outgoing:

Call No. with international / national prefix:

Ringback tone to CO:

Name in CO:

Segmentation: ▼

deactivate UUS per route:

Always use DSP:

Depending on the dialling behaviour the flag “Add seizure code for MEX” must be configured accordingly (see example 3.1b). Default value is “false”, so the user has to dial external destinations with leading seizure code (e.g. “0” or “9”). If it shall be possible to dial external destinations without seizure code then this flag must be activated. This flag is in System Flags:

Expert mode - Telephony Server

Basic Settings

System

System Flags

Time Parameters

Display

DISA

Intercept/Attendant/Hotline

LDAP

Texts

Flexible menu

Speed Dials

Service Codes

HFA Registration Password

Gateway

DynDNS

Quality of Service

System Flags

Edit System Flags

SPE advisory tone:

Transparent dialing of * and # on trunk interfaces:

Add seizure code for MEX:

CMI MWI Ringer:

Automatic OpenStage / Desk Phone CP TDM Phone Software Update:

Restrict indirect trunk group connections according to CON Matrix:

Apply Undo Help

MEX number that was set in the wizard is stored under the ITSP Route. You may find/edit it in Expert Mode > Trunks Routing:

Expert mode - Telephony Server

Trunks/Routing

- Trunks
 - Route
 - ISDN
 - Trk Grp. 2
 - Trk Grp. 3
 - Trk Grp. 4
 - Trk Grp. 6
 - Trk Grp. 6
 - Trk Grp. 7
 - UC Suite
 - Trk Grp. 9
 - Trk Grp. 10
 - Trk Grp. 11
 - Trk Grp. 12
 - Trk Grp. 13
 - myITSP MEX**
 - Trk Grp. 15
 - Networking
 - QSIG-Feature
 - MSN assign

Route

Change Route | Change Routing Parameters | Special Parameter change

Route Name: myITSP MEX

Seizure code: 857

CO code (2nd trunk code):

Gateway Location

Country code: 49

Local area code: 89

PABX number:

PABX number-incoming

Country code: 49

Local area code: 89

PABX number:

Location number:

PABX number-outgoing

Country code:

Local area code:

PABX number:

Suppress station number:

Overflow route

Overflow route: None

Digit transmission

Digit transmission: en-bloc sending

Mobile Extension Number (MEX)

MEX Number: 35800

Trusted External Users

Trusted External Users:

Apply | Undo | Help

Now the system is ready to work with MEX prefix as described in configuration examples.

