

Dokumentation

HiPath OpenOffice ME/EE

Gigaset S3 professional in HiPath Cordless IP

User Guide

Communication for the open minded

Siemens Enterprise Communications
www.siemens.de/open

SIEMENS

Safety notes

Handset



Danger:

- Do not use the handset in potentially explosive atmospheres.
 - To avoid mutual interference, do not operate the handset in the vicinity of electronic equipment.
 - Do not use the handset in wet rooms! Devices are not splash-proof.
 - A transmitter signal is emitted by your handset. Please observe safety procedures for your area.
-



Note:

The ringing tone, signal tones and handsfree talking (speakerphone mode) are played over the loudspeaker. Do not hold the telephone to your ear when it is ringing or if speakerphone mode is switched on. Otherwise you may seriously impair your hearing.



Note:

- Information for hearing aid users: Radio signals can interfere in hearing aids.
 - Please provide the operating instructions with the handset if giving it to another user.
-

Battery pack



Danger:

- Only use the original rechargeable battery pack recommended by Siemens.
 - Do not use a standard rechargeable battery pack. This can result in serious injury and material damage (risk of explosion, degradation of battery pack cladding, functional interference and handset damage).
 - Avoid contact with fire and water.
 - Only use the approved C39280-Z4-C373 power supply unit to operate the charging shell.
-


WEEE mark

**Note:**

- All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- The correct disposal and separate collection of your old appliance will help prevent potential negative consequences for the environment and human health. It is a precondition for reuse and recycling of used electrical and electronic equipment.
- For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service, the shop where you purchased the product or your sales representative.
- The statements quoted above are only fully valid for equipment which is installed and sold in the countries of the European Union and is covered by the directive 2002/96/EC. Countries outside the European Union may have other regulations regarding the disposal of electrical and electronic equipment.



Overview of handset



- | | |
|--------------------|---------------------------|
| 1 Receiver inset | 10 Call-by-call key |
| 2 Display | 11 Hash key |
| 3 Display keys | 12 Number keys |
| 4 Control key | 13 On-hook and on/off key |
| 5 Speakerphone key | 14 Message key |
| 6 Talk key | |
| 7 Star key | |
| 8 R key | |
| 9 Microphone | |

How to use the keys: → Page 7

Contents

Overview of handset IV

Operating instructions 1

Conducting calls – the basic functions 1

Activating/deactivating the handset.	2
Dial first, then seize the line	3
Manual number redial	3
Enquiry.	4
Answering or rejecting a call	5
Ending a call.	6
Activating or deactivating the keypad lock	6
After leaving the radio network	6

Description of controls 7

Function keys	7
R key	8
Control key	8
Display keys.	9
Menu icons in the main menu.	11

Putting the handset into service 12

Removing the protective cover	12
Inserting the batteries	12
Charging and using the batteries.	14
Batteries operating times and charging times	15
Permitted batteries	15
Fitting the attachment clip.	15
Setting the handset display language	16

Setting the handset 18

Setting the speaker volume.	18
Setting the ringer.	19
Advisory tones.	20
Setting ringing tones and pictures with resource directory	21

- Viewing pictures/playing sounds 21
- Renaming a picture 22
- Deleting pictures 23
- Checking the available memory 23
- Activating or deactivating the ringer 24
- Activating or deactivating the warning tone 24
- Activating/deactivating automatic call answering 25
- Setting the date and time 26
- Display settings 27
- Setting the conversion list for vCard transfer 31
- Resetting the defaults 32

Conducting calls – enhanced functions34

- Speakerphone mode 34
- Conducting calls with the headset 35
 - Corded headset 35
 - Cordless headset 35
- Number redial 38
 - Automatic redial 38
 - Deleting a redial entry or list 38
 - Adding a telephone number to the redial list 39
 - Entering a phone number in the call-by-call list 40
- The handset’s phonebook/call-by-call list 41
 - Saving an entry 42
 - Finding and dialling an entry 43
 - Dialling an entry with the speed dialling digit 44
 - Viewing an entry 44
 - Changing an entry 44
 - Marking a VIP (Very Important Person) entry 45
 - Deleting an entry or phonebook/call-by-call list 46
 - Displaying available memory 46
- Using dual-tone multifrequency signalling 47

Conducting calls – with multiple users48

- Transferring a call 48
- Placing a call on hold 49
- Toggling (switching between calls) 49
- Conducting a conference 50

Message functions51

- Caller list 51

Additional functions52

Handset alarm clock function	52
Handset appointment reminder function.	54
Selecting a base	57
Speed access to functions and phone numbers	58
Data exchange between a PC and a handset or between two handsets	60
Interface overview	60
PC application (Gigaset QuickSync)	60
PC interface (Bluetooth)	61
Bluetooth interface	62


Telephone blocking.65

Handset telephone lock.	65
Telephone lock code programming	66
Locking/unlocking the handset	67

Appendix68

Troubleshooting.	68
Cleaning the handset.	70
Documentation	71
Technical data	71
Charging shells	71
Accessories	72
EU guidelines.	72
Declaration of conformity	73

Index74



Step by step

Operating instructions

These operating instructions describe your handset and its functions on your communications system.

All functions that can be performed via your handset are described here. If some of the required functions are not available on your handset, it may be due to one of the following:

- The function is not configured for you or your handset - please contact your system administrator.
- Your communications platform does not feature this function - please contact your Siemens contract partner to upgrade.

Conducting calls – the basic functions

You can use your handset to make both internal and external calls.

Internal calls are calls that

- you make within the range of a communication system, for example, within your company,
- you make between networked communication systems, for example, to different company locations.

External calls are calls that you conduct with users of the public telephone network.

Step by step

Activating/deactivating the handset



Press the On-hook key until the activation or deactivation is confirmed by a crescendo tone sequence.

PIN

If the default PIN has not been changed (0000), the handset is ready for operation as soon as it is switched on. If a PIN was set, it must be entered before the handset can be operated.

Please enter PIN:



Enter the PIN



Confirm your entry. The handset is ready to use.

Displaying the connection quality

The strength of the incoming signal is displayed by the "receive field strength" icon in on or message status:

D>>>	flashing, no reception
▮>>>	Low receive field strength
▮▮>>	50% receive field strength
▮▮▮>	75% receive field strength
▮▮▮▮	100% receive field strength

The radio range is different indoors and outdoors (→ Page 71). Please consult your system administrator in the event of range problems.

Charging the batteries

You may only use the charging shell provided for the handset.

The handset charges when sitting in the charging shell, even when deactivated. If the handset is active, the charging status display flashes on the display.

If the handset deactivates because the battery pack is flat, it automatically reactivates and is ready for operation as soon as you place it in the charging shell. The charging operation starts. If a PIN was set, it must be entered first to allow charging to start.

Step by step



and if necessary



or



either:



Or:

Call rejected



or



If applicable, **Show**

either:



or



or:

Options

Language

If your preferred language for the display texts is not set, you can set this yourself (→ Page 16).

Dial first, then seize the line

Dialling preparation:

Enter the required phone no. and correct individual characters as necessary using the "Delete" Display key.

Dialling:

Press the answer or speakerphone key within 30 seconds. The station is called.

The station answers. You are conducting a call.

The station is busy or rejects the call. If configured you are connected to the station's mailbox.

Press the On-hook key briefly.

Manual number redial

The last 20 phone numbers dialled are saved in the redial list. A phone number that was dialled several times is only saved once.

When the handset is idle: Press the Talk key briefly. The redial list is displayed.

Select the required telephone number.


If you want to see details on the selected phone number: Press the display key.

Press the Talk or Speakerphone key briefly. The connection is set up.

Open the redial menu. The menu contains the following functions (→ Page 38):

- Copy to Directory
- Automatic Redial
- Display Number
- Delete Entry

Step by step



- Delete List
- Select the menu item and confirm.



Change or complete the phone number, for example, with DDIA.



Press the Talk or Speakerphone key briefly. The connection is set up.


Enquiry

You interrupt your call to consult with a user (including external users) and then resume the original call.



You are on a call.

Activating and conducting an enquiry/consultation call



Activate consultation. The current call is placed "on-hold" so that the first user waits.



Enter the phone number for the consultation call.




The number is dialled. The user answers. The consultation starts.

The second user is busy or does not answer




Abort consultation. You are reconnected with the first party.



Call an additional station


or:




You are reconnected with the first party.

End the callback call and return to the waiting call

either:




The second station hangs up.



Call an additional station

or:



You are reconnected with the first station.

Step by step

You are reconnected with the first call party. The second call party hears a busy tone and hangs up. A Gigaset phone hangs up automatically.

You can however also

- talk alternately with call parties (toggle/connect) (→ Page 51),
- set up a conference (conference) (→ Page 52) or
- transfer the waiting call party to the second call party (press the disconnect button) (→ Page 50).

Answering or rejecting a call


Answering a call

Your handset rings (→ Page 25). The caller information appears on the display. The name and/or telephone number of the caller can be displayed. The following options are available for answering a call:

either

Tone off

Press the display key. The phone continues to ring at the calling party's end. You exit the room with the phone..




or

or



The phone is in the charging cradle: Take the phone out of the charging cradle (only works when "Auto call answer" is activated → Page 27).



or



The phone is out of the charging cradle: Press the Talk or Speakerphone key.

Once you have answered the call you can:

- Transfer the call (Initiate callback function) (→ Page 50),
- place the call on hold (microphone off) to execute a callback in the room (→ Page 51),
- place the call on hold (callback function) and call a second call party (→ Page 4), to forward the held call (→ Page 50), to toggle (→ Page 51) or to set up a conference (→ Page 52).


Rejecting a call

If you do not wish to be disturbed, you can reject the call.

Step by step

Reject

Confirm the message displayed with one of the two display keys. The call is rejected and the caller hears the busy tone. You are routed to the other party's mailbox (if configured) .



Ending a call

Press the On-hook key briefly or place the handset in the charging shell.

The call charges are displayed, depending on the communication system.

Activating or deactivating the keypad lock

This feature protects against accidentally pressing buttons when the handset is in a pocket, forexample. The keypad lock turns off automatically when a call comes in and turns back on when the call has ended.



Press the hash key until the activation or deactivation is confirmed by a crescendo tone sequence.

A key icon on the display indicates that keypad lock is active.

After leaving the radio network









The base name flashes on the display. The handset repeatedly attempts to synchronise with a base. The intervals between synchronisation attempts increase on account of the integrated power saving function.

You can switch off your handset to save the battery pack.

Description of controls

Function keys

The following function keys are available:

Key	Name	Use
	On-hook and on/off key	<ul style="list-style-type: none"> • End a call • Cancel functions • Jump back to the previous menu (only following Options) • Activate or deactivate the handset
	Talk key	<ul style="list-style-type: none"> • Answer a call • Dial a phone number • Open the redial list • Access telephone system functions
	Speakerphone key	<ul style="list-style-type: none"> • Answer a call • Dial a phone number • Toggle between handset to speakerphone mode • Access telephone system functions
	Message list	Access message lists
	Star key	Activate/deactivate the ringer
	Hash key	Activate/deactivate keypad lock
	Call-by-call key	Open the call-by-call list
	R key	R key function (→ Page 8)





R key

Pressing the R key quickly performs different functions depending on the current operating mode, for example:

- When dialling: insert a pause (for example, between the prefix and the phone number, or when checking a mailbox)
- During a call: A callback is initiated
- During a callback call: Toggling between the stations


















Control key

The control key is assigned different functions depending on the operating situation:

Situation	 Press top of key	 Press bottom of key	 Press left side of key	 Press right side of key
In idle status	Set the ringer	Open the mobile's telephone directory		Short: Open the handset's main menu
During a call	Set the voice/telephone volume	Open the mobile's telephone directory		Select "Loudspeaker Vol", "GAP DTMF", "Base Settings"
In the main menu	Select a menu icon	Select a menu icon	Select a menu icon	Select a menu icon
In lists and menus	Next-higher item in the list	Next-lower item in the list	Next menu level up, cancel	Select an entry (OK)
In the input field	Move the cursor up one line	Move the cursor down one line	Move the cursor left	Move the cursor right
Change values			Reduce value	Increase value

Display keys

The handset has two display keys, each with one or two functions. When the key is allocated two functions, press the right or left side of the key to select the corresponding function. Display key assignment depends on the operating status. A function can be represented by text or an icon.

Icon	Name	Use
	Menu	Open the handset's main menu or a situation-specific menu
	Delete	Delete the entry character by character from right to left
	Go Back	Go back to the next highest menu level, cancel
	OK	Confirm the selected menu item
	Up/down	Scroll up or down to select menu items
	Define a function	Program a function for the left display key. Displayed until a function is programmed.
	Change	Change the configuration
	Play	Play a melody
	2ndCall	Accept call waiting
	View	Display entry or picture
	Off	Deactivate automatic redial/function
	End	End melody playback
	Beep	Activate the warning tone
	Yes	Confirm the security check question
	Toggle	Toggle between two partners
	Options	Open a context-specific handset menu
	Enquiry	Make an enquiry/consultation

Icon	Name	Use
Silent	Silent	Confirm handset appointment reminder call
Set	Set	Set number keys
Save	Save	Save entries
Appoint.	Appoint.	Activate handset appointment reminder function
Dial	Dial	Dial the digits entered
Alarm	Alarm	Activate alarm function
Time	Time	Enter the time and date. Displayed until the time and date are set.

Additional icons can be displayed by programming the left display key with a function, for example, the name of a directory or call-by-call entry (→ Page 58).

Menu icons in the main menu



You can open the handset's main menu by pressing the "Menu" display key or by pressing the right control key.

The main menu is a graphical menu and contains the following menu icons:


Icon	Use
	Open the "Add. Features" menu. Contains the menu items "Data Transfer" and "Missed Dates".
	Open the mask for setting the alarm clock. You can enter a wake-up time here.
	Open "Calendar". Displays the calendar for the relevant month and allows you to set a new reminder. The list of fixed reminders also appears.
	Open the "Resource Dir." menu. Contains the menu items "Screensavers", "Caller Pictures", "Sounds" and "Available Memory".
	Open the "H/Set Settings" menu. This menu contains the following items: "Date/Time", "Audio Settings", "Display", "Handset" and "Base".
	Icon for caller list: functions analog to messages key.



The menu icons are selected by pressing the top, bottom, right or left of the control key.

Putting the handset into service

Removing the protective cover



Remove the protective cover from the display before putting the handset into service.

Inserting the batteries

The handset is supplied with the approved batteries. The batteries are not loaded. It is first charged in the handset.




Note:

- Note: Please observe the safety notes on the back cover.
- Only use the approved batteries (→ Page 15).
- Open the battery compartment in a dust-free environment only.
- Your telephone directory entries and all settings remain stored even if you remove the batteries. The date and time settings will be reset.
- Only remove the batteries if it is defective. The batterie's life diminishes each time it is removed.

1. Removing the attachment clip (if installed)


Insert a screwdriver between the attachment clip and the battery cover (1) and force the attachment clip outward (2) until it dislodges.



Also release the clip on the reverse side and then remove.

2. Opening the battery compartment

Insert a screwdriver into the groove between battery cover and the jack, grip the cover firmly and lift it off the battery compartment.




3. Inserting the batteries

Insert the approved batteries making sure that the poles are facing the right directions as indicated.



4. Closing the battery compartment

Position the battery cover over the compartment's catches so that they can snap into place. Then press the battery cover down until it snaps into place.



Charging and using the batteries

To charge the batteries, insert the handset into the charging shell with the keypad facing forwards.



Attention:

Only use the relevant approved power supply units for operating the charging shell (for order numbers see → Page 71).

The charging status is indicated by the charge status display. This flashes during charging:

	Batteries empty
	Batteries 33% charged
	Batteries 66% charged
	Batteries 100% charged



Note:

- Initial charging: Charge the batteries for at least 10 hours without a break, regardless of the charging status icon. Without replacing it in the charging shell, use the handset until the "battery low" beep is heard. This action aligns the charge status display with the operating times of the batteries.
- To attain full operating and charging times (→ Page 15): Without replacing it in the charging shell, use the handset until the "battery low" beep is heard.
- For future charging: you can place your handset in the charging shell each time it is used. Charging is electronically controlled which ensures that the batteries are charged optimally.

Batteries operating times and charging times

The operating times are only achieved after several charging and discharging cycles and are dependent on

- the battery capacity,
- the age of the batteries,
- the settings made,
- the user behavior,
- the DECT cordless system used

Capacity (mAh)	Stand-by mode (hours)	Talk time (hours)	Charging time (hours)
800	> 150 ^a approx. 110 ^b	approx. 9	approx. 9

a. Operation at a Gigaset bases, such as, Gigaset S300 professional

b. Operation at HiPath Cordless Enterprise/HiPath Cordless Office


Permitted batteries

The following batteries are approved for use with the handset.

Batterie
Sanyo NiMH, 800 mAh
GP, 850 mAh
Yuasa Technologies AAA, 800 mAh

Fitting the attachment clip

Press the attachment clip onto the back of the handset until the tabs on the sides engage in the recesses on the phone.



Step by step

Setting the handset display language

If your preferred language for the handset's display texts is not set by default, then you can set it yourself. The language of the communication system's display texts can only be set by the administrator.


Opening the main menu



Open the handset's main menu.


Opening the first submenu

either:



Select the menu icon and confirm.


or:



Select the menu icon and confirm.

Opening the second submenu

either:



Select the menu item and confirm.


or:



Select the menu item and confirm.


Opening the third submenu

either:



Select the menu item and confirm.

or:



Select the menu item and confirm.

Step by step



Deutsch
English
Francais
Italiano
Espanol
Portugues
Nederlands
Dansk
Norsk
Svenska
Suomi
Cesky
Polski
Turkce
Ellinika
Magyar
Russkij
Hrvatski
Slovenscina
Romana

OK




Selecting a language

Select and confirm the language you require.

Press the On-hook key to end the operation.



Note:

- If you inadvertently set a display language that you do not understand, press " 5 3 1" and then select the correct language.
- If you want to reset the default display language: → Page 32.

Step by Step

Setting the handset

You can change the standard settings of the handset if you are not happy with them.

Setting the speaker volume

You can adjust the speaker volume during a call. The following volumes are adjustable:

- Volume in handset mode. Three volume levels are possible.
- Volume in speakerphone mode. Five volume levels are possible. You can only change the speakerphone volume if the speakerphone is active (→ Page 34).


You are on a call.

Open the handset's main menu.

Select the menu icon and confirm.




Select the menu icon and confirm.

Select the menu icon and confirm.



Define settings.

Press the display key if you want to permanently save the setting.



Step by Step


Setting the ringer

Setting the ringer volume and melody

Tones and melodies are saved on your handset. When selecting the menu, the ringer sounds at the current setting. You can choose between three ringer volumes, as well as a crescendo ring (volume increases gradually).

You can activate distinctive ringing tones on your handset to help you differentiate between calls and appointments:

- Ext. Calls
- Internal calls
- Appointments
- All




Open the handset's main menu.

Select the menu icon and confirm.

Select the menu item and confirm.

Select the menu item and confirm.

Select the required menu item and confirm. The input mask, for example, for external calls is displayed.



1 Ringer volume

2 Ringer melody



Set volume.



Move the cursor down one line.

...

etc.



Please make sure that you have picked up the call before holding the phone to your ear. This is to ensure that the loud ringing tone does not cause damage to your hearing.

Save

Save the settings.

Step by Step

Advisory tones

The advisory tones have the following meaning:


Advisory	Meaning
Key tone	Every keystroke is confirmed
Confirmation tones	<ul style="list-style-type: none">Confirmation tone (crescendo tone sequence) when saving inputs/settings and when placing the handset in the charging shellError beep (decreasing tone sequence) to signal incorrect inputsEnd-of-menu beep at the menu end
Battery tone	The batteries need to be charged

H/Set Settings

Audio Settings

Advisory Tones

- Open the handset's main menu.
- Select the menu icon and confirm.
- Select the menu item and confirm.
- Select the menu item and confirm. The input mask, for example, for advisory tones, is displayed.



- 1 Key tone status
- 2 Confirmation tone status
- 3 Battery tone status





- Define settings.
- Move the cursor down one line.
- ...
- Save the settings.
- Press the On-hook key to end the operation.

Step by Step

Setting ringing tones and pictures with resource directory


Your handset’s resource directory is used to manage sounds that you can set as ringing tones and pictures that you can use as screensavers. Sounds are preset and can be neither modified, loaded nor deleted.


The resource directory can manage the following media types:

Icon	Media type	Format
	Monophone ringing tones	Standard
	Polyphone ringing tones	Standard
	Polyphone ringing tones	.mid
	Picture (screensaver)	BMP 128 x 128 or 128 x 64 pixels)

The icon is displayed in the resource directory before the name. Your handset comes with a number of mono- and polyphone sounds pre-installed. Loading/deleting sounds is not supported. You can download pictures from a PC (→ Page 60) and listen to existing sounds.

Viewing pictures/playing sounds



- Open the handset’s main menu.
- Select the menu icon and confirm.
- Select the required menu item and confirm.
- Select the entry.
- Press the display key. Sounds are played back or pictures are displayed.
- Press the display key. The handset finishes playing the sound or displaying the picture.
- While playing back sounds, you can use the  key to interrupt playback.

Step by Step



Press and hold down the On-hook key to end the operation. The telephone reverts to idle mode.

If an error message appears

An error message appears after you select a picture if you saved the image in an invalid file format. Press to interrupt the operation. Press to delete the picture.

Setting the sound volume during playback



Sound 1
Sound 2
...



Select the required sound and confirm. The volume can be set to five different levels in the input mask.



Press the display key.



Press the display key.



Adjust the volume.



Save settings.

Renaming a picture



Open the handset's main menu.



Resource Dir.



Select the menu icon and confirm.



Screensavers
Caller Pictures



Select the required menu item and confirm.



Select the entry.



Open the menu.



Rename



The name of the entry can be modified. Length: up to 15 characters. Then confirm your entry.



Press the On-hook key to end the operation.


Step by Step

Deleting pictures

A picture that cannot be deleted is marked with . In this case, the functions listed below are not available.



Open the handset's main menu.



Select the menu icon and confirm.




Select the entry.




Open the menu.

either:



Select the menu item and confirm. The selected entry will be deleted.

or:



Select the menu item and confirm. All deletable entries in the list are deleted.




Press the On-hook key to end the operation.

Checking the available memory


You can show how much memory is left.



Open the handset's main menu.



Select the menu icon and confirm. The amount of memory available/used is displayed:



13% of the available memory is free.



Press the display key. The display ends.

Step by Step

Activating or deactivating the ringer

Deactivating the ringer



Hold down the key until a confirmation tone is emitted.



The ringer is deactivated.

Activating the ringer



Hold down the key until a confirmation tone is emitted.

Deactivating the ringer for the current call



Hold down the key until a confirmation tone is emitted.

Reactivate the ringer after the call so that the handset uses the ringer to signal the next call.

Activating or deactivating the warning tone

When you activate the warning tone, all other tones are deactivated. An incoming call is signalled by this brief tone.

If the handset is in a call pickup group, a pickup call is also signalled by the warning tone.

Activating the warning tone



Hold down the key until a confirmation tone is emitted.

Beep on

Press the Display key within three seconds.



The warning tone is activated. The volume of the warning tone is coupled with the volume of the external ringer.

Deactivating the warning tone










Hold down the key until a confirmation tone is emitted.

Step by Step

Activating/deactivating automatic call answering






This function allows you to accept calls by removing the handset from the charging shell.



H/Set Settings

Handset

Auto Answer



Open the handset's main menu.

Select the menu icon and confirm.

Select the menu item and confirm.

Select the menu item and confirm.

Automatic answering is activated.

The activated function is ticked and can be deactivated by selecting it once more.

Press the On-hook key to end the operation.

Step by Step

Setting the date and time

The handset date and time are automatically set when you set up a call to another station. If your communication system does not support this function, you can set the date and time manually. The handset data and time must be set so that calls receive the correct timestamp.

either:



Open the handset's main menu.



H/Set Settings



Select the menu icon and confirm.



Date/Time



Select the menu item and confirm.

or:

If the date and time have not yet been set:



Press the display key.

then:



Enter the date, forexample, 22.09.2009 = 220909.



Move the cursor down one line.



Enter the time, for example, 19:05 = 1905.



Save the settings.



Press the On-hook key to end the operation.

Note:

HiPath Cordless IP overwrites the set time of the handset.


Step by Step

Display settings

A number of options are available for setting the display. You can set the screensaver (screen picture), the colour scheme, the contrast and the display lighting. You can also change the name displayed for the base station.

Screensaver

You can set a screensaver that is displayed when the handset is idle. It replaces the idle status display and can even overlap the date, time and the name of the base station. The screensaver is not displayed during a call or if the handset is logged off.



Open the handset's main menu.

Select the menu icon and confirm.

Select the menu item and confirm.

Select the menu item and confirm. The mask for activating and setting the screensaver is displayed.

Activation: **On** **either:**

View **or:**

Selection: **Beach**

Edit **then:**

Save

The active screensaver is displayed.

Move the cursor down one line.

Select a picture, for example "Beach".
Tip: If you select the "Clock" screensaver, the time is shown in large digits on the display.

The selected screensaver is activated.

Save the settings.


Press the On-hook key to end the operation.

Step by Step

Colour scheme

Four colour schemes are saved on your handset. By selecting a colour scheme you define the colours to be used for the font, menu items and background.

If you change to a different colour scheme during a setting, it is immediately previewed to show how it will appear later for all menus.



Open the handset's main menu.

Select the menu icon and confirm.

Select the menu item and confirm.

Select the menu item and confirm. The colour scheme selected is displayed.

Selecting the colour scheme.


Confirm your selection.

Save setting.

Press the On-hook key to end the operation.

Contrast

Use this function to define the contrast between the font/menu icons and the background.



Open the handset's main menu.

Select the menu icon and confirm.

Select the menu item and confirm.


Select the menu item and confirm. The mask for setting the contrast is displayed.

Set the contrast.


Save setting.

Press the On-hook key to end the operation.


Step by Step



In Charging shell:



Outside Charging shell:



Save



Lighting

You can set whether the display should light up when the handset is in the charging shell or if it is out of the charging shell.

Open the handset's main menu.

Select the menu icon and confirm.

Select the menu item and confirm.

Select the menu item and confirm. The mask for setting lighting is displayed.

Enable or disable activation.

Move the cursor down one line.

Enable or disable activation.

Save setting.

Press the On-hook key to end the operation.

Base station name

You can change the base station name that is displayed in idle status. The handset must be registered at the corresponding base.

Open the handset's main menu.

Select the menu icon and confirm.

Select the menu item and confirm.

Select the menu item and confirm.

Select the menu item and confirm.

The selected base is activated. The activated base is ticked. It can be deactivated by selecting another base.


Change the settings.

Delete text.

Enter the required text and correct individual characters as necessary using the "Delete" Display key.

Save the settings.

Press the On-hook key to end the operation.



Change

Edit Name: <C



and if necessary <C

Save



Step by Step



Press the On-hook key twice to turn the handset off and back on.

The new base station name is now displayed in idle status.

The HiPath Cordless IP system overwrites the "base name" display as soon as the line is seized. The name of the base station is displayed in this case only after the handset has been switched off and on again.

Step by Step

Setting the conversion list for vCard transfer

Phone numbers are usually specified as follows in e-mail programs, such as, Microsoft Outlook: +49 (05251) 820776. The handset is unable to use this format, however, to dial the phone number. If the phone number above is a local fixed network number, it is converted to 0820776, for instance. The conversion pairs are defined in the conversion table and can be modified if they deviate from the default values.


Consult your system administrator about the conversion rules that apply to your handset.

Defining conversion pairs

Open the handset's main menu.




Select the menu icon and confirm.



Select the menu item and confirm.



Select the menu item and confirm. The conversion table is displayed. It is predefined for the country in question and may be displayed in the following format:



- 1 The country code "49" is replaced by "00"
- 2 The area code, for instance "05251" (blank in this example), is replaced by "0"



Change entry.

Press the top/bottom control key to navigate to another input field; press the left/right control key to move the cursor within an input field.



Save setting.



Press the On-hook key to end the operation.

Step by Step




Resetting the defaults

This function allows you to reset your mobile phone to the defaults, for example, if you want to pass it on to someone else or reset it.

The handset features are handled as follows:




Feature	Action
Sound settings	are reset
Call-by-call list	is retained
System registration	is retained
Phonebook	is retained
Redial list	is deleted

Resetting






H/Set Settings

OK



Handset

OK




Reset Handset

OK

Yes

- Open the handset's main menu.
- Select the menu icon and confirm.
- Select the menu item and confirm.
- Select the menu item and confirm. A security check question appears.
- Confirm the security check question. The handset is returned to the default.

 **Note:**
For information about deleting the telephone directory see: → Page 46.

Default settings

Setting	Explanation/notes	Levels	Default state
Tones and signals	Ringer volume	5	5
	Ringer melody, external	3 +30	1
	Ringer melody, internal	3 +30	3
	Warning tone	-	off
	Handset volume	3	1
	Volume in speakerphone mode	5	3
	Appointment		
	Melody	3+30	1
	Volume	5	5
	Key tones, audible each time a key is pressed.	-	on
	Warning tone, audible approximately five minutes before the battery runs out.	-	on
	Confirmation tone, indicates whether actions were successful or unsuccessful.	-	on
Auto Answer	Call is automatically accepted by removing the handset from the charging shell.	-	on
Select Base	Select the base	4	retained
Lighting	Display lighting	-	on
Screen Picture	Display in idle status	-	off
Character Set	Available character set	-	Standard
Language	Select different languages:	20	English or German
Bluetooth	Bluetooth-Activation	-	off
Default state	Resetting the defaults deletes the redial call numbers and resets the sound settings. The registration (login) and the handset PIN are retained.	-	-

Step by Step

Conducting calls – enhanced functions

Speakerphone mode

Features

Speakerphone mode offers you the following advantages:

- Other persons can listen to and participate in the call.
- Your hands are free.
- When dialling, you can hear the ring tone, for example, without having to lift the handset to your ear.

Speakerphone mode can be used effectively up to a background noise level of 50 dB (A) (Office environment).

Activating speakerphone mode

Speakerphone mode can be activated during a call, when dialling or when answering a call:



Press the Speakerphone key. The Speakerphone key lights up. Inform the other party when you want to activate the speakerphone to let others listen in.



Note:

Make sure you switch back to handset mode before you return the telephone directly to your ear. In this way you can avoid causing damage to your hearing.

Switching between speakerphone and handset mode



Press the Speakerphone key. The handset switches from speakerphone to handset mode or vice versa.

The Speakerphone key lights up if speakerphone mode is active. It does not light up if speakerphone mode is deactivated and handset mode is activated.

Step by Step

**Note:**

If you wish to replace the handset in the charging shell during a call, for example, because the batteries are flat, hold down the Speakerphone key to prevent the call from being cleared down.

Setting the speakerphone volume

The volume can be set during a call (→ Page 18).

Conducting calls with the headset

The handset can be used with a corded and cordless headset.

Corded headset

You can connect a corded headset to the socket on the side. The headset must have a 2.5 mm plug.

The receiver inset and microphone functions are activated on the headset once it is connected.

Cordless headset

You can use a cordless, Bluetooth-enabled headset with your handset. This means your hands are free while making calls and there are no annoying cables to disrupt your computer work in the office or on the road, for example.


Your Bluetooth headset must be registered on your handset before you can use it for the first time. After this, you can continue to use your Bluetooth headset until you decide to deregister it.




**Note:**



- Theoretically, third parties can tap Bluetooth connections.
- To improve protection against unauthorised tapping, deregister any Bluetooth devices you no longer require.



During a call, a second caller is not signalled via the Bluetooth headset.



Step by Step





 Extras



 Data Transfer



 Bluetooth



 Search Headset

 Found Devices
S55 Headset

Options

 Trust Device

 agreed PIN:

 Activation ☐

☒

OK

OK

OK

OK

OK

OK

OK

OK

Registering a Bluetooth headset at the handset

Set the headset to login mode (see the user manual supplied with your headset).

Open the handset's main menu.

Select the menu icon and confirm.

Select the menu icon and confirm.

Select the menu item and confirm. The Bluetooth menu is displayed.

Select the menu item and confirm. The handset searches for a Bluetooth headset and sets up a wireless connection. The name of the devices found are displayed.

Select the required headset.

Open the handset's menu

Select the menu item and confirm.

Enter and confirm the Bluetooth PIN for your headset (see your headset user manual). The device is recorded in the list of known devices.

The Bluetooth interface is automatically activated on your handset.

The active Bluetooth function is ticked.

Conducting calls via the Bluetooth headset

Activating the Bluetooth headset during a call

If the handset is in dial or call mode (establishing a call connection → Page 3), the Bluetooth headset can assume the receiver inset and microphone functions.

Press the Talk key on the Bluetooth headset (refer to the headset user manual).

36

Step by Step



Accepting a call on the Bluetooth headset

The headset uses a call tone to signal an incoming call. Press the Talk key on the Bluetooth headset (refer to the headset user manual).

Deactivating the Bluetooth headset during a call

You are conducting a call via the Bluetooth headset.



Press the Talk key or Speakerphone key on the handset. The Bluetooth headset is deactivated. You can continue the call directly on the handset.

Deregistering the Bluetooth headset at the handset

To improve protection against unauthorised tapping, deregister the Bluetooth headset at the handset if you no longer wish to use it.



Open the handset's main menu.



Extras



Select the menu icon and confirm.



Data Transfer



Select the menu icon and confirm.



Bluetooth



Select the menu item and confirm. The Bluetooth menu is displayed.



Trusted Devices
S55 Headset



Select the menu item and confirm. The name of the registered or recognised Bluetooth headset is displayed.

Options

Open the handset's menu



Delete Entry



Select the menu item and confirm. The Bluetooth headset is deregistered or no longer recognised by the handset.

Step by Step

Number redial




The last 20 phone numbers dialled are saved in the redial list. A phone number that was dialled several times is only saved once.



If you tried to call a party from the handset’s telephone directory, the name of the party is displayed in case of number redial. For information on manual number redial, see (→ Page 3).


Automatic redial

The phone number is automatically redialled ten times at 20-second intervals. Speakerphone mode is automatically activated, the Speakerphone key flashes. The function is deactivated after ten unsuccessful attempts and when a call is made in the interim.

Press the Talk key briefly. The redial list is displayed.
Select the required telephone number.
Open the redial menu.


 or 
Options

  Automatic Redial **OK**

either:

or:
Off




Select the menu item and confirm. Automatic redial is activated.



The user answers and you conduct the call.

If you wish to cancel the function: press the Display key or any key.

Deleting a redial entry or list

Press the Talk key briefly. The redial list is displayed.
Select the required telephone number.
Open the redial menu.


 or 
Options

either:
  Delete Entry **OK**
or:

Select the menu item and confirm. The telephone number is deleted.

Step by Step



Delete List



Select the menu item and confirm. The redial list is deleted.




Press the On-hook key to end the operation.

Adding a telephone number to the redial list


During dial preparation, you can add a number displayed in the handset's redial list to your phonebook.



Press the Talk key briefly. The redial list is displayed.



Select the required telephone number.



Open the redial menu.



Copy to Directory




Select the menu item and confirm. The phonebook is displayed.



New Entry



Select the menu item and confirm. The following selection mask appears:



- 1 Tel.
- 2 Tel. (office)
- 3 Tel. (mobile)



Mark the line where you want to insert the phone number.





Confirm your entry.





Enter the remaining contact information, such as, first name and surname. For further information, see → Page 41 and → Page 42.



Step by Step





New Entry



...



Save



Entering a phone number in the call-by-call list

You can manually enter a phone number in the call-by-call list.

- When the handset is idle: Open the call-by-call list.
- Select the menu item and confirm. The input mask is displayed. The line where you can enter information is marked active with [...].
- Enter the relevant information, see above.
- Jump to the next line.
- etc.

Functions for text input:

	Switches mode from abc to Abc, from Abc to 123 and from 123 to abc If predictive text is off: press the key briefly. If predictive text is on: press and hold down the key.
	Deletes the letter to the left of the cursor.
	Opens the table of special characters.

- Save the settings.
- Press the On-hook key to end the operation.

The handset's phonebook/call-by-call list

A total of up to 250 entries can be saved in the phonebook and the call-by-call list. The phonebook and the call-by-call list are operated in the same way.

Gigaset QuickSync → Page 60 is a software application for transferring data between your cordless Gigaset phone and your PC. You can use it at your phone to load data from your PC to your Gigaset over a data cable or Bluetooth and synchronize contacts with Microsoft Outlook, Microsoft Outlook Express, and contacts in Microsoft Windows Vista.

Phonebook:

You can save contact information for frequent call partners in the phonebook. Once a phone number has been saved in this way you no longer have to enter it in full when you want to call someone. All you have to do is select the required phonebook entry.

You can save the following contact information for every entry in the phonebook:

Information	Explanation
First Name*, Surname	A name must be entered in at least one of the fields. Each name can contain up to 16 characters.
Phone, Phone (Mo- bile)*, Phone (Of- fice)*	A number must be entered in at least one of the fields. Each number can contain up to 32 digits.
E-Mail*	E-mail address with up to 60 characters. The special character "@" can be inserted after pressing the asterisk key.
Anniversary	You can select either "On" or "Off". If "On" is selected: <ul style="list-style-type: none"> • Anniversary (Date): Day/month/year, 8 digits* • Anniversary (Time): Hour/minute, 4 digits, for reminder call • Anniversary (Signal): Type of signalling, acoustic or visual (time specification not necessary)
CLIP picture*	Displays a picture for an incoming call when CLIP is active. Note: This function is not supported by the system and should therefore not be used.
VIP Entry	VIP mark and VIP ringing tone. Reached by pressing Options .

* = new for vCard format


Step by Step

Call-by-call list:

You can save carrier prefixes, for instance, in the call-by-call list. The following information applies to each entry.

Information	Explanation
Number:	Up to 32 digits
PublicKey:	Up to 16 characters

Saving an entry



When the handset is idle: Open the phonebook or call-by-call list.

Select the menu item and confirm. The input mask is displayed. The line where you can enter information is marked active with [...].

Enter the relevant information, see above.

Jump to the next line.

etc.

Functions for text input:

	Switches mode from abc to Abc, from Abc to 123 and from 123 to abc If predictive text is off: press the key briefly. If predictive text is on: press and hold down the key.
	Deletes the letter to the left of the cursor.
	Opens the table of special characters.

Save

Save the settings.



Press the On-hook key to end the operation.

Step by Step

Changing the sequence of entries:


The phonebook entries are generally sorted in alphabetical order by surname. Spaces and digits have first priority here. If the phonebook only contains a subscriber's first name, this is listed instead of the surname in the sequence.

The sort sequence is as follows:

1. Space
2. Digits (0 - 9)
3. Letters (alphabetical)
4. Other characters

If you want to change the sequence of entries in the alphabetical list, you could insert a space or a digit before the first letter of the surname. These entries then move to the top of the phonebook. Names preceded by an asterisk are listed at the end of the phonebook.

Finding and dialling an entry



or



When the handset is idle: Open the phonebook or call-by-call list.



or



You can scroll to the required entry or enter the first letter of the relevant entry.
If necessary, press a key several times in succession to enter the required letter.

either:



Press the Talk key. The assigned phone number is dialled.

or:

Options

Open the menu.



Display Number

OK

Select the menu item and confirm. The number is displayed.



Change or complete the phone number, for example, with DDIA.



Press and hold down the Talk key.

Step by Step

Dialling an entry with the speed dialling digit

You can call up and dial the phone number associated with an entry that you saved in the call-by-call list and assigned a speed dialling digit by simply pressing this speed dialling digit (→ Page 58).




Press and hold down the required speed dialling digit. The assigned phone number is shown on the display.



Press and hold down the Talk key. The assigned phone number is dialled.

Viewing an entry



or



When the handset is idle: Open the phonebook or call-by-call list.



or



You can scroll to the required entry or enter the first letter of the relevant entry. If necessary, press a key several times in succession to enter the required letter.



Press the display key. The entry's data is displayed.




Confirm to return to the list.



Press the On-hook key to end the operation.

Changing an entry



or



When the handset is idle: Open the phonebook or call-by-call list.




or



You can scroll to the required entry or enter the first letter of the relevant entry. If necessary, press a key several times in succession to enter the required letter.

either:



Press the display keys one after the other. The entry's data is displayed.

or:



Open the menu.



Edit Entry



Select the menu item and confirm. The entry's data is displayed.

Step by Step

then:



Enter changes.

Options

Open the menu.



Save Entry

OK

Save the entry.



Press the On-hook key to end the operation.

Marking a VIP (Very Important Person) entry



When the handset is idle: Open the phonebook.



Select the required entry.

Options

Open the menu.



VIP Entry

OK

Select the menu item and confirm. The input mask for marking a VIP entry is displayed.

VIP:  **Ein** 

Activate the VIP marking.



Move the cursor down one line.

Melody:  **Circles** 



Select a melody, foreexample, "Circles".




Press the On-hook key to end the operation.

Step by Step


Deleting an entry or phonebook/call-by-call list

 or 


 

Options


either:

  Delete Entry **OK**

or:

  Delete List **OK**

Yes



When the handset is idle: Open the phonebook or call-by-call list.

Select the required entry.

Open the menu.



Select the menu item and confirm. The telephone number is deleted.



Select the menu item and confirm. A security check question appears.

Confirm the security check question. The phonebook/call-by-call list is deleted.



Press the On-hook key to end the operation.


Displaying available memory

 or 

Options

  Available Memory **OK**



When the handset is idle: Open the phonebook or call-by-call list.

Select any entry.

Open the menu.

Select the menu item and confirm. The amount of memory used and available is displayed.

Press the On-hook key to end the operation.

Using dual-tone multifrequency signalling

Your handset operates on the basis of digital information transmission. However, certain applications, for example, answering machines, can only be operated using analog technology. For this you must send signals using the dual-tone multifrequency signalling (DTMF) process.

Depending on how your system is configured (automatic tone dialling on or off - to be configured by the service engineer) you must first switch to DTMF dialling. This means, for example, that you can communicate with a variety of voice storage systems.

You will find further details in the operating instructions for the relevant applications.

When you are in call mode, MFW dialing is always activated.

Step by step

Conducting calls – with multiple users

Transferring a call

Transferring a call means that you wish to hand over a call you are conducting on your handset to another user.

Transferring (without announcing the transfer)



You can use this function to forward a call which you answered to another user.

Hold



Enter the number of the station to which you want to transfer the call. The current call is on hold and the first station waits.



The number is dialed.



Press the disconnect key. The phone rings at the destination station. He answers the call by lifting the receiver.

You receive a recall:

- if after a period of time after transferring the required call party does not respond.

Transfer (with call transfer notification)



You are on a call which you want to transfer to another station.

Hold



Enter the number of the station to which you want to transfer the call.



The number is dialed. The station answers. You announce the held call.



Press the disconnect key. The destination stations takes over the call.

Step by step

Placing a call on hold

You can interrupt a call temporarily if, for example, you want to talk to someone else in the room. The line is placed "on hold" .



You are on a call.



or

Enquiry

Press the R key or Display key. The current call is placed "on hold", the user waits.

Resuming the call with the waiting user



or

Retrieve

Press the R or display key.

You are reconnected with the call party.

Toggling (switching between calls)

The Toggle function allows you to switch between two users without allowing them to speak to each other directly. The two users can be either external or internal users. You can also withdraw from the calls and connect the two users with each other. You can also start a conference.



You are on a call.

Menu

Call the system menu.

Enquiry

Press the display key. The current call is placed "on hold" , the user waits.



Enter the phone number of the second user.



The second user answers.

Toggle

Press the Display key to switch between the two calls.

When you end a call, the two users are connected with each other (not possible when both users are external).

Step by step

Conducting a conference

You can connect up to 3 internal and external call partners in a telephone conference.

Setting up a conference

You decide to set up a conference while talking to a user.

You are on a call and wish to start a conference.

Press the R or display key.

Enter the number of the second station.

The station is free and answers. You announce the conference.

Open the system menu.

Select the menu item and confirm.

You and your two call partners are connected in a conference.

Ending a conference

You are connected with two or more partners in a conference call.

Call the system menu.

Select the menu item and confirm. The first station is disconnected from the conference.





Select the menu item and confirm. The second station is disconnected from the conference.

Press the disconnect key. The conference is ended.

Leaving a conference

Press the On-hook key. You leave the conference.

When one user leaves the conference, the other two users remain connected.



Step by step

Message functions

Caller list

If you are unable to answer an external and/or internal call, this call request is stored in a caller list.

Your handset can store up to 10 calls in chronological order. Every call is given a timestamp. The display starts with the latest call request still not called. When several calls are received from one caller, the number of calls is shown.

Entries in the call lists can be added to the redial list.



Note:

If the service engineer has made the appropriate configuration, the phone numbers for all external answered calls are automatically saved.

Select call list



Press the INT key.



Call lists



Select the menu item and confirm. The call lists for missed and answered calls are displayed.



Select call list.

Call back caller



Select station and press the Talk key. The connection is set up.

Delete the callers from the call list



Press the INT key.



Call lists



Select the menu item and confirm. The call lists for missed and answered calls are displayed.



Select call list.



Select station.

Delete entry



Select the menu item and confirm. The entry is deleted.


Press the On-hook key to end the operation.

Step by Step

Additional functions

Handset alarm clock function

When the alarm clock is activated, it rings every day or every day from Monday to Friday at the set time. The alarm clock is deactivated during automatic number redial.

**Note:**

The alarm will only sound with the set melody if the handset is in idle status. During a call, the alarm is only signalled by a short tone. Date and Time must be set.

Prerequisite: The date and time must be set.

Activating the alarm clock


The handset is in idle status.

Open the handset's main menu.

 Alarm Clock



Select the menu icon and confirm. The input mask for setting the alarm is displayed.



1 Alarm activation: on/off
2 Time in format [HH:MM], foreexample, 19:05 = 1905
3 Alarm rings every day or only Monday - Friday
4 Volume can be set to five different levels + crescendo ring
5 Adjustable melody

1 Alarm Clock: On



2 Time: [HH:MM]


3 Period: Daily


4 Volume: [Bar graph]


5 Melody: Circles

Save

 On 







...

Save

- Define settings.
- Move the cursor down one line.
- Enter the time.
- Move the cursor down one line.
- etc.
- Save the settings.

Step by Step



The alarm clock is activated.



Press the On-hook key to end the operation.

Deactivating an alarm/repeating after a pause

The alarm rings for 60 seconds. The following appears on the display: . If you do not press anything, the alarm repeats after five minutes and then deactivates.

During the alarm:

either:

Off

Press the display key. The alarm deactivates.

or:

Snooze

Press the display key or any key. The alarm deactivates and is repeated after five minutes. The alarm is repeated twice and then permanently deactivated.

Deactivating the alarm clock

The handset is in idle status.



Open the handset's main menu.



Alarm Clock

OK

Select the menu icon and confirm. The input mask for setting the alarm is displayed.

Activation:



Off



Define settings.

Save

Save setting.



Press the On-hook key to end the operation.

Step by Step

Handset appointment reminder function

You can program your handset to remind you of up to thirty appointments. The handset must be in idle status at the time of the appointment reminder. The appointment reminder function is deactivated during automatic number redial.

The ringer melody and volume are set under Audio Settings/Ringer Settings/Appointments. The date and time must be set.

Saving an appointment

The handset is in idle status.

Open the handset's main menu.

Select the menu icon and confirm. The current month's calendar is displayed with the current day marked.

Select and confirm the required day for the new appointment reminder. The input mask for entering a new appointment reminder appears.

Select and confirm the menu item or select an existing appointment entry. The "New Entry" option only appears if an appointment entry already exists.

Define settings.

Move the cursor down one line.

Enter the date, for example, 11 November = 1111.

Move the cursor down one line.

Enter the time, for example, 19:05 = 1905.

Move the cursor down one line.


Enter the name for the appointment reminder.

If applicable, delete the old text.

Save the settings.

The appointment reminder function is activated.

Press the On-hook key to end the operation.



Step by Step

Confirming an appointment reminder call

An appointment reminder call is signalled in the same way as an incoming call.

Press the display key during the appointment reminder call.

If you do not confirm the appointment reminder call, it will be stored in a missed dates list.

Deactivating an appointment reminder

The handset is in idle status.

Open the handset's main menu.

Select the menu icon and confirm. The current month's calendar is displayed with the current day marked.

Confirm the current day. The list of appointments is displayed.

Select and confirm the appointment reminder that you want to deactivate.

Call the additional menu.

Select the menu item and confirm. The appointment reminder marked is deactivated.

Save setting.

Press the On-hook key to end the operation.

Deleting an appointment reminder or the entire list of appointment reminders

The handset is in idle status.

Open the handset's main menu.

Select the menu icon and confirm. The current month's calendar is displayed with the current day marked.

Confirm the current day. The list of appointments is displayed.

Select and confirm the appointment reminder that you want to delete.

Call the additional menu.

Off



Calendar



New Entry
11.11, 22:22
11.11, 23:23 ...



Options



Deactivate



Save



Calendar



New Entry
11.11, 22:22
11.11, 23:23 ...



Options

Step by Step

Delete Entry

OK

Delete List

OK

Yes

Save

Appt.

Add. Features

OK

Missed Dates

OK

OK

Delete

Select the menu item and confirm. The appointment is deleted.

Select the menu item and confirm. A security check question appears.

Confirm the security check question. The appointment reminder list is deleted.

Save setting.

Press the On-hook key to end the operation.

Displaying an unconfirmed appointment

If you have failed to confirm an appointment reminder call, a Display key is assigned the "Missed Appoint." function. This unconfirmed appointment must also be saved in a missed dates list.

Display an appointment. The date and time of the unconfirmed appointment are displayed.

Displaying an unconfirmed appointment and unconfirmed anniversaries

Any appointment reminder calls and anniversary calls you fail to confirm are stored in a missed dates list.

Open the handset's main menu.

Select the menu icon and confirm.

Select the menu item and confirm. A list of missed/unconfirmed appointments is displayed. The last appointment missed is always on top and the oldest is last.

Select an unconfirmed appointment or an unconfirmed anniversary. The relevant information is displayed.

If applicable, delete the selected appointment.


Press the On-hook key to end the operation.

Step by Step

Selecting a base

If your handset is registered at multiple bases, then you can set a specific base or the base with the best reception as the base to be used. The handset then switches automatically to this base.

You can change the base name that is displayed on the handset at any time (→ Page 29).



Open the handset's main menu.

Select the menu icon and confirm.

Select the menu item and confirm.

Select the menu item and confirm.

Select the required base and confirm. The selected base is ticked.

- Base 1 - 4: Select base n to specify the precise HiP-ath cordless system where the handset is registered.
- Best Base: If the handset is registered at multiple cordless systems, it automatically switches to one of these systems when it enters the relevant range. For example: The handset is registered at the Giga-set home base as well as at the cordless system in the company.



Press the On-hook key to end the operation.

Step by Step

Speed access to functions and phone numbers

You can program the left display key and the number keys 0, 2 to 9 with a phone number or function. You can then dial the phone number or start the function programmed by simply pressing the appropriate key.

Configuring speed access

either:

0 / 2 ... 9 Press the required number key briefly.

If this key is already programmed with a function, it appears on the left display key. The number key can be programmed with a new function.

Set Press the display key.

or:

0 / 2 ... 9 / ? Press and hold down the required number key or the left display key.


then: A list of functions that can be programmed on the key is displayed. The following functions are available for selection:

- Speed dialling
- Call-by-call (→ Page 41)
- INT
- Alarms (→ Page 52)
- Calendar
- Bluetooth



Select and confirm the function.

If you selected the "speed dialling" or "call-by-call" function:



Select the required phone number and confirm.

Step by Step

Starting a function, dialling a phone number

either:

0 / 2 ... 9 Press and hold down the number key programmed with the required function. Or press the left display key briefly.

or:

0 / 2 ... 9 Press the number key programmed with the required function briefly. The function is displayed on the left display key.

Forexample: **Alarm Clock** Press the left display key briefly.

then: Depending on how the key is programmed, the following occurs:

- A phone number from the handset's telephone directory is dialled.
- A phone number from the call-by-call list is dialled.
- The menu associated with the programmed function is opened.

Data exchange between a PC and a handset or between two handsets

You can transfer data between a PC and your handset or between two handsets.

Interface overview

The handset supports the following interfaces for data exchange:

Interface	Connect via...	Data transfer between...
Bluetooth interface	Radio, cordless	PC <-> handset handset <-> handset

PC application (Gigaset QuickSync)

You can use the PC application, for example, for read and write access to your handset's directory as well as download pictures (.bmp) for the screensaver from the computer to the handset. The PC application must be installed on your PC for this. It can be downloaded as freeware from the Internet.

"Data Transfer" is shown on the display during data transfer between the handset and PC. No inputs are possible via the keyboard when this operation is active and incoming calls are ignored.

The PC application supports different DECT handset types.

For more detailed information, refer to the Gigaset QuickSync help function under: www.siemens.com/GigasetSL370.

PC interface (Bluetooth)

You can use the PC interface (Bluetooth) to read, modify and transfer phonebook entries and pictures to the mobile phone.

Data transfer mode

Certain functions necessitate the transfer of large volumes of data between the handset and the computer. When these functions are selected, the handset switches to data transfer mode and "Data Transfer" appears on the display. In this mode, no inputs are possible via the keyboard and calls are ignored.

The handset is switched to data transfer mode by:

- activating read/write access to the phonebook
- loading screensavers



The handset automatically switches to idle if a fault occurs in the course of transferring data.

Step by Step

Bluetooth interface

If you have installed a Bluetooth interface on your PC, you can also communicate with the PC application via the Bluetooth interface on your handset.



Note:

Theoretically, third parties can tap Bluetooth connections.

Transferring a phonebook from handset to handset via Bluetooth

Prerequisite: The Bluetooth interface on the other handset (→ Page 64) must be active.

If the Bluetooth connection is not yet established between the handsets, perform the following steps:

On your handset

Open the handset's main menu.

Select the menu icon and confirm.

Select the menu icon and confirm.

Select the menu item and confirm. The Bluetooth menu is displayed.





Select the menu item and confirm. The handset searches for a Bluetooth data device and sets up a wireless connection. The name of the devices found are displayed.




Select the required device, for example, the other handset.




Open the handset's menu




Select the menu item and confirm.



Enter the Bluetooth PIN and confirm (default: 0000). The device is recorded in the list of known devices.




 Add. Features 




 Data Transfer 




 Bluetooth 




 Search Data Device 




 Found Devices
S3 professional




 Trust Device 




 agreed PIN: 










































































































































































































































































































































































































































































































































































































































































Step by Step



agreed PIN:

OK

Enter the Bluetooth PIN immediately and confirm (default: 0000). If you were not fast enough, repeat the previous steps.



Add to
Trusted Device
list?

OK

Confirm the prompt.

The Bluetooth connection is established. The two handsets can now exchange data in vCard format.

Transferring data



Open the phonebook.



Select the entry.



Open the handset's phonebook menu.

either:



Copy List

OK

Select the menu item and confirm.

or:



Copy Entry

OK

Select the menu item and confirm.

then:



vCard via Bluetooth:

OK

Select the menu item and confirm.




Trusted Devices
...

OK

Select and confirm the target device or handset. The vCard data is sent to the target device.

Now follow the instructions on your handset display.

Step by Step



Deactivating and activating the Bluetooth interface

You can deactivate the Bluetooth interface if you do not need it for extended periods of time. This increases your handset's stand-by time.

Deactivating the interface

- Open the handset's main menu.
- Select the menu icon and confirm.
- Select the menu icon and confirm.
- Select the menu item and confirm. The Bluetooth menu is displayed.
- Select the menu item and confirm. The Bluetooth interface is deactivated.
- ☐ The check box is not marked if the Bluetooth function is deactivated.

Activating the interface

- Follow the procedure described above to activate the Bluetooth interface.
- ☒ The active Bluetooth function is ticked.

Step by step

Telephone blocking

Handset telephone lock

You can protect your handset against unauthorised access by entering a 4-digit numerical code to lock it.

The PIN is preset to "0000" (default). The handset does not prompt for a PIN in this setting. As soon as you have changed the PIN you will need to enter it when you turn on the handset.

Enter the value "0000" again to deactivate the PIN.



Attention:

If you have forgotten your PIN, please contact Siemens Service. The PIN will be reset at your own expense.

Entering a new PIN

   H/Set Settings



Open the handset's main menu.

  Handset



Select the menu icon and confirm.

  Change HSPIN



Select the menu item and confirm.



Enter the old PIN. If a PIN has not yet been set, then enter "0000".



Enter the new PIN.



Move the cursor down one line.



Repeat the new PIN.



Confirm your entries.



Press the On-hook key to end the operation.

Battery charging when PIN lock active

If the handset deactivates because the batteries are flat, it automatically reactivates as soon as you place it in the charging shell. The charging operation starts. If you have already set a PIN, you must enter it so that the handset can receive calls.

Step by step

Telephone lock code programming

You can protect your handset against unauthorised access (thereby safeguarding personal data) by entering a 5-digit code to lock and unlock it.

To change a code, first enter the old code and then key in the new code twice.

Press and hold down the Talk key or press the Speakerphone key.

Call the system menu.

Select the menu item and confirm.

Select the menu item and confirm.

Enter the old code (5 digits, default "00000").

Enter the new PIN, forexample, 11111 (5 digits).

Repeat the new PIN.

Press the On-hook key to end the operation.




Note:

If you have forgotten your PIN, contact your service engineer for help. He will be able to re-set your PIN to "00000".
It is also possible to open your mobile phone from a central station, forexample, from the attendant terminal.




Menu



Service?

OK



*93=Change PIN?

OK



Step by step

Locking/unlocking the handset

You can lock your handset to prevent external dialling and programming, thereby preventing unauthorised use in your absence, for example.

Prerequisite: You have defined a personal code or use the default code "00000".

Locking the handset



Press and hold down the Talk key or press the Speakerphone key.

Menu

Call the system menu.



Changeover on?

OK

Select the menu item and confirm.



Enter the PIN code (5 digits, default "00000").



Press the On-hook key to end the operation.



Note:

Even though it is locked, you can still use your handset to answer external calls and make internal calls. When an external connection is established, the following message appears on the display "Telephone Lock Active".

Your handset can also be locked from a central station (→ Page 66).

Unlocking the handset



Press and hold down the Talk key or press the Speakerphone key.

Menu

Call the system menu.



Changeover off?

OK

Select the menu item and confirm.



Enter the PIN code (5 digits, default "00000").



Press the On-hook key to end the operation.

Appendix

Troubleshooting

Some malfunctions can be resolved without outside intervention. The following table provides a list of such malfunctions. All other malfunctions should be reported to the relevant service personnel.

Error	Possible cause	Remedy
No display.	Handset not switched on.	Press the On-hook key until confirmation is received.
	The batteries are flat.	Charge or replace the batteries.
You cannot dial a phone number.	The handset is locked.	Unlock the handset.
No reaction to key-stroke.	Keypad lock activated.	Press the hash key until confirmation is received.
	The key is stuck.	Release the key.
De-crescendo tone sequence during input.	An incorrect entry was made.	Repeat key sequence while watching the display; where applicable, consult the operating instructions.
The line "Base n" flashes (n= 1 - 4).	The handset is outside the base radio range; radio signals too weak.	Come closer to the base radio range, change your position.
	Handset not registered.	Register the handset.
	Intervals between synchronisation attempts are too long.	Switch off the handset and switch it back on again.
No ringer on the handset.	Ringer is deactivated.	Activate ringer.
	"Do Not Disturb" is activated.	Deactivate "Do Not Disturb".
Nothing audible during a call.	The "R key" was pressed – the microphone and the receiver inset are muted.	Press the "Delete" display key to re-activate the microphone and the receiver inset.

Error	Possible cause	Remedy
The following appears immediately after the Talk key is pressed: Connect. No dial tone available; no calls can be made.	Communication system is being used by other users.	Repeat call later.
The following, for example, appears: Base 1 Outgoing and incoming calls and activation/deactivation are not possible.	Handset is blocked.	Remove the batteries from the handset and then re-insert it. Proceed as when loading batteries for first time (→ Page 14).
The following appears: Time exceeded	Maximum input time was exceeded. The On-hook key was not pressed.	Avoid long pauses between keystrokes. Press the On-hook key.
The following appears: Please try later	The communication system is overloaded.	Wait and try again later.
The following appears: Currently not accessible	Function is currently not available. No connection available under the phone number dialled.	Wait and try again later. Enter the phone number correctly or call the attendant console.
The following appears: Not possible or: Incorrect input or: Nothing stored	Speed dial number not available, appointment entered incorrectly, entry blocked or not allowed, prerequisite not fulfilled (for example, if there is no second partner for toggling), number dialled was incomplete.	Correct your input, select a permitted option, enter the phone number in full.
The following appears: Not authorized	Blocked function was called.	Apply to the relevant service personnel for the COS for the blocked function.
The following appears: Not allowed	Incorrect PIN was entered.	Enter the correct PIN.

Error	Possible cause	Remedy
The following appears: Not available	Phone number was not fully entered, the star or hash key was not pressed.	Enter the phone number correctly or as pre-scribed.
The following appears: Do not disturb	Data transfer is active.	Wait and try again later.

Cleaning the handset

Removing everyday dirt

To clean the handset and the charging shell, simply wipe them with a damp or anti-static cloth. Never use a dry cloth.
Do not use abrasive cleaning agents.

After contact with liquids

1. Deactivate the handset immediately. Do NOT activate it!
2. Remove the batteries immediately. Leave the battery compartment open.
3. Allow the liquid to drain off:
 - Hold the handset in a horizontal position with the open battery compartment facing down.
 - Hold the handset in a vertical position with the open battery compartment facing down. Shake the handset gently, tilting it slightly back and forth.
 - Dab all components dry and then leave the handset in a warm spot (not beside a microwave, oven, etc...) for at least 72 hours with open battery compartment and keypad facing down.

The handset can be put back into operation once it is completely dry.

Storage

To avoid damage, the handset should not be stored with sharp objects, such as, knives or tools, etc. We recommend keeping the handset in a protective pouch when in use (→ Page 72).

Documentation

These operating instructions can be found in PDF format at the following URL:

<http://www.siemens.com/hipath>

and on CD-ROM (ask the service personnel) in HTML and PDF format.

To view or print the operating instructions in PDF format, you need a computer on which the free Adobe Acrobat Reader program is installed.

To view the operating instructions in HTML format, you need a computer with a Web browser, for example, Microsoft Internet Explorer.

Technical data

Maximum sound pressure level according to TBR10, Annex D:	less than 118 dB (A)
Operating and charging times:	→ Page 15
Permissible ambient conditions for operation:	+5 °C to +45 °C 20 % to 75 % relative humidity
Weight incl. batteries:	approx. 119 g
Batteries:	→ Page 15
Dimensions (W x H x D):	approx. 50 x 143 x 30 mm

Charging shells

Gigaset S3 professional Charger EU	S30852-H1980-R142
Gigaset S3 professional Charger UK	S30852-H1980-L142
Gigaset S3 professional Charger US	S30852-H1980-R342
Gigaset S3 professional Charger AUS	S30852-H1980-C442

Accessories

Only use original accessories. This will help you avoid injury and property damage and you can ensure that all relevant regulations are observed.

Headset:

Headsets from different manufacturers may be used

Source

For information on accessories (such as, headsets, data cables, protective pouches), contact Siemens at the following address:

Siemens AG, I&S IS SC S RC, Tübingerstr. 1-5, 80686 Munich

Mr. Jens Schwabe

Tel.: +49 89 9221 - 3174

Fax: +49 89 9221 - 6603

E-mail: jens.schwabe@siemens.com

EU guidelines

The handset and accessories listed conform to the following EU guideline:

99/05/EC "Radio and Telecommunication Terminal Equipment"

Declaration of conformity

Your handset is supplied for use within a specific country, which is displayed on the underside of the device. Country-specific features must be observed.

The device complies with the basic requirements of the R&TTE Directive and therefore displays the CE marking.

Extract from original declaration

"We, Siemens AG, declare, that the above mentioned product is manufactured according to our Full Quality Assurance System certified by CETECOM ICT Services GmbH with the registration number "Q810820M" in compliance with ANNEX V of the R&TTE Directive 99/05/EC. The presumption of conformity with the essential requirements regarding Council Directive 99/05/EC is ensured."

Senior Approvals Manager

The Declaration of Conformity (DoC) has been signed. In case of need, a copy of the original DoC can be made available via the company hotline.

CE 0682

Index

A

Accessories	72
Activating	2
Advisory tones	20
Alarm	52
Allocating	48
Ambient conditions	71
Appointments	
Activating	54
Confirming	55
Deactivating	55
Displaying	56
Handset ~	54
Attachment clip	
Fitting	15
Audio functions	18
Auto answer	25
Automatic number redial	38
Available memory	46

B

Base	
Changing the Name Displayed	29
Selecting	57
Batteries	
Capacity	15
Charging	2, 14
Charging time	15
Inserting	12
Operating time	15
Permitted ~	15
Stand-by time	15
Talk time	15
Warning tone	33
Battery tone	
Setting	20
Bluetooth	35
Bluetooth interface	62

C

Call-by-call list	41
Caller list	51

Calls

Accepting	5
Answering	5
Making	3
Rejecting	5
Capacity	15
Changing a phone number	44
Charge status	14
Charging time	15
Cleaning	70
Clip	
Fitting	15
Code programming	66
Colour scheme, setting	28
Conference	
Ending	50
Leaving	50
Setting up	50
Confirmation tone	
Function	33
Setting	20
Connection quality	2
Consultation (second line)	4
Contrast, setting	28
Control key	IV, 8

D

Data transfer	61
Date, setting	26
Deactivating	2
Declaration of conformity	73
Default state	32
Deleting	
Call-by-call list	46
Entry	38, 46
Phonebook	46
Redial list	38
Dialling	
A phonebook entry	43
Before line seizure	3
Dialling a number	43
Dimensions	71
Display	IV
Colour scheme	28
Contrast	28
Lighting	29
Screensaver (screen picture)	27

Settings	27
Display keys	IV, 9
Display lighting	29

E

Entry	
Changing	44
Deleting	38, 46
Dialling	3, 38, 43
Marking as VIP	45
Saving	42
Searching for	44
Viewing	44
EU guidelines	72
Everyday dirt	70

F

Function keys	7
---------------------	---

G

Guidelines	72
------------------	----

H

Handset	
Locking/unlocking	67
Handset operating times	15
Hash key	IV, 7
Headset	35

I

Icons	11
Interface	61, 62
Interference with electronic equipment	
EMC	II

K

Key tones	
Function	33
Setting	20
Keypad lock	6
Keys	
Control key	8
Display keys	9

Function keys	7
---------------------	---

L

Language setting	
Handset	16
Leaving the radio network/ re-registering	6
Line seizure	3
Liquids	70
Locking/unlocking the telephone	67

M

Mailbox function	51
Main menu	11
Making calls	3
Making calls with the headset	35
Manual number redial	3
Memory	46
Menu icons	11
Message functions	51
Message key	IV
Message list	7
Messages	51
Microphone	IV

N

Number keys	IV
Number redial	
Adding a phone number	39
Automatic	38
Deleting an entry/list	38
List	3, 38
Manual	3
Number, applying	43

O

On hold	49
On/off key	IV, 7
On-hook key	IV, 7
Opening/closing battery compartment ..	13

P

Parts of the device	IV
---------------------------	----

PC interface	61
Permitted batteries	15
Phone number	
Changing	44
Dialling from the phonebook	43
Saving	42
Phonebook	
Handset ~	41
Phonebook entries, sorting	43
PIN	2, 65, 66, 67
Placing a call on hold	49
Prefixes, converting	31
Programming keys	58
Protective cover	12
Protective pouch	70

R

R key	IV, 7, 8
Radio range	2
Range problems	2
Recall	48
Receiver inset	IV
Rejecting a call	5
Reset	32
Resource directory	21
Ringing	19

S

Saving a phone number	42
Second line (consultation)	4
Setting the ringer	19
Setting the screen picture	27
Setting the screensaver	27
Sorting phonebook entries	43
Sound pressure level, maximum	71
Speaker volume	18
Speakerphone key	IV, 7
Speakerphone mode	34
Speed access to functions	58
Speed dialling	
Call-by-call key	IV
Dialling	44
Stand-by time	15
Star key	IV, 7
Storage	70
Switching between calling parties	49

T

Talk key	IV, 7
Talk time	15
Technical data	71
Telephone blocking	66
Telephone lock	66
Telephone volume	18
Time, setting	26
Toggle	49
Tone dialling	47
Tones	19, 20
Transfer	48
Transferring	48
Transferring a call	48
Troubleshooting	68

V

vCard	41
Converting prefixes	31
VIP	45
Volume	18

W

Warning tone	24, 50
Function	33

Communication for the open minded

Siemens Enterprise Communications
www.siemens.com/open

Copyright © Siemens Enterprise
Communications GmbH & Co. KG
Hofmannstr. 51
80200 München
Deutschland

Siemens Enterprise
Communications GmbH & Co. KG
is a Trademark Licensee of Siemens AG

Reference No:
A31003-G2100-U110-1-7619

The information provided in this document contains merely general descriptions or characteristics of performance which in case of actual use do not always apply as described or which may change as a result of further development of the products.

An obligation to provide the respective characteristics shall only exist if expressly agreed in the terms of contract. Availability and technical specifications are subject to change without notice. OpenScape, OpenStage and HiPath are registered trademarks of Siemens Enterprise Communications GmbH & Co. KG. All other company, brand, product and service names are trademarks or registered trademarks of their respective holders.