

# OpenScape Business

# How To Configure SIP Trunk for BluNetworks NL

#### **Table of Contents**

C	onfiguration Data	. 3
	onfiguration Wizard	
_	Internet Telephony	
	Internet Telephony configuration	
	Define bandwidth (# Trunks)	
	Special phone numbers	

### **Table of History**

Date	Version	Changes
08.03.2019	1.0	First version for V2R7
06.09.2024	1.1	editorial changes

**Note**: The basis for this document is the current OpenScape Business at the time of certification. Since OpenScape Business is constantly developed, input masks and interfaces as well as requirements may change in the future. The settings and entries described here then apply accordingly.

## **Configuration Data**


Information from ITSP BluNetworks NL

Name	Example
Call Number:	(085) 79204607920469
Gebruikersnaam:	31857920460
Wachtwoord:	e.g. 58#\$II9*
Number of voice-channels:	2


#### **Configuration Wizard**

#### **Internet Telephony**

Go to "Central Telephony – Internet Telephony"




The overview page appears for entering the location data. The most flexible type of configuration is to enter the Country code only.




In this case, remaining digits are filled in DID field. Click [OK & Next]

Provider configuration and activation for Internet Telephony -> No call via Internet -> uncheck Use County specific view : Netherlands and select BLU Networks.




Activate Provider and click on [Edit].

The following settings are shown. They should not be changed.



#### **Internet Telephony configuration**


In this dialog the specific customer SIP Userdata will be configured.



Click on [Add].

Data provided by ITSP BluNetworks is inserted here.





Internet telephony station: "Gebruikersnaam" is inserted here.

Authorization name: "Gebruikersnaam" is inserted here.

Password: "wachtwoord" provided by ITSP BluNetworks is inserted here.

Call number assignment: select "Use public number (DID)". This is the easiest and preferred

way to define the phone numbers in the system. Phone numbers are treated as a normal DID number in the system as if it was normal


ISDN.

ITSP multiple route: Has to be used in case more then one account of the same provider


(in this case BluNetworks) has to be configured on the same system. When this flag is activated you will be able to define extra accounts.

Default number: Main number of connection. The default number is used as outgoing


number when no DDI number is assigned to a station. (number must be in Implicitly international format)




#### Click [OK & Next].



Click [OK & Next].




Click [OK & Next] (no input needed)



Click [OK & Next] (no input needed)

#### **Define bandwidth (# Trunks)**


In the next part the number of simultaneous calls via the SIP trunk will be defined. The calculation of the number of trunks is done by the wizard automatically depending on the bandwidth. For each 128K, one trunk is created. The number can also be defined manually.




Click [OK & Next]

#### Special phone numbers

In this dialog it is possible to route special phone numbers. When special phone numbers are not supported over the ITSP route it is possible to change this here.



Click OK & Next and the ITSP status will be displayed



In case status LED is orange there is something wrong in the previous configuration.

After this status page the dialog with "Exchange Line Seizure" is displayed.

Here you need to configure your own local area code. This is needed to make external calls without the area code. The LCR will be adapted accordingly.

